

SINGER | Studio S18

The SINGER S18 Studio computerized sewing & quilting machine provides you with the high performance of a dealer-grade sewing machine for a fraction of the cost. Boasting over 400 Built-In Stitches including 7 Styles of Fully Automatic 1-Step Buttonholes the possibilities are limitless. This computerized sewing machine allows you to store up to 50 stitch pattern combinations and recall them at the touch of a button. With block and script letters and numbers available in 5mm and 7mm sizes, you can create custom quilt labels appropriate for the project size. Advanced features like Programmable Needle Up / Down for quilting and appliquéing, Pattern Elongation, Stitch Memory with Editing and Automatic Thread Cutter ensure that this is a sewing machine you will love for years to come.



Advanced Features Add A Professional Touch

Computerized Sewing Machine with Memory & Editing

Create stitch pattern combinations with the built-in Memory. Store up to 50 stitch pattern and retrieve them even after the machine has been turned off. Edit the stitches for unique project embellishments.

Extension Table Included

The extra-large extension table measure 23" in length by 15" in width. The convenient ruler allows you to make quick measurements up to 18".

Large Back-Lit LCD Screen

Clearly see important information like Selected Mode, Number and Image of Selected Stitch, Stitch Length, Stitch Width, Single or Twin Needle Settings, Letter and Image of Recommended Presser Foot, Recommended Tension Setting, Recommended Presser Foot Pressure settings. Change the screen's brightness according to your room's lighting. Choose from 10 language options.


Independent Bobbin Winding System

Continue to sew while filling a bobbin! Simply follow the numbered diagram printed on the top of sewing machine and your bobbin is full in no time!



Extra-Large Sewing Space

With almost 9" x 6" of bed space to the right of the needle, the long arm design allows you to manage quilts and other large projects with ease.



Large Back-Lit LCD Screen

Clearly see important information like a picture of the selected stitch, recommended presser foot, tension settings and more.

SINGER® | Studio S18

Automatic Settings Eliminate Guesswork

Automatic Electronic Thread Trimmer

Simply press the scissors button and the top and bobbin threads are trimmed. You can even program this sewing machine to automatically trim the threads at the end of a programmed stitch combinations.

Automatic Stitch Length & Width


Optimal settings for stitch length and width are automatically set, but can be overridden for more personalized sewing.

Variable Speed Control

Use the Speed Control lever to set the maximum sewing speed for precise topstitching or beginner sewing. Sewing at a maximum speed of 1,000 stitches per minute allows you to finish your projects efficiently.

Extra-High Presser Foot Lifter

Offers more clearance when sewing bulky fabric.



Easy Threading with Automatic Needle Threader

Sewing's biggest timesaver easily threads the needle without eye strain. Simply follow the instructions printed on the machine for accurate threading.



Presser Foot Sensor

Ensures the presser foot is in the proper position for an easy start. The machine will not begin to sew if the presser foot is raised, reducing the chance of thread bunching.



Knee Lifter Included

The knee lifter allows for hands-free raising and lowering of the presser foot and is vital when pivoting and quilting.



Independent Bobbin Winding System

Continue to sew while filling a bobbin! Simply follow the numbered diagram printed on the top of sewing machine and your bobbin is full in no time!

Top Drop-In Bobbin System

The bobbin loads from the top, so it is easy to insert the bobbin. Simply follow the illustrations pictured on the machine. The clear cover makes it easy to monitor the bobbin thread supply.

Complete Stitch Control

The Electronic Foot Controller provides you with precision at lower speeds and helps maintain smooth and even sewing at all speeds. You can sew through multiple layers of denim and thick quilts at low speeds without worry.

Dual Spool Pins with Retractable Guide

The right spool pin is a must-have with utilizing the independent bobbin winding system. The retractable spool guide handles cones of thread with optimal thread tension.

Adjustable Thread Tension

Ensures stable stitch quality regardless of fabric type. Simply turn the dial on the top of the machine for even stitches. Consult the LCD screen for recommended thread tension setting.

Unleash Your Creativity

15 Needle Positions

Needle position can be changed for individual projects like inserting zippers or cording and topstitching.

7mm Stitch Width

Most stitches can be set for a maximum width of 7mm creating attractive satin and decorative stitches.

Locking Stitch Button

Auto-lock decorative and utility stitches with just a push of the Locking Stitch Button. Three tiny tacking stitches reinforce patterns and stitches to prevent unraveling.

Automatic Twin Needle Mode

Select stitches automatically adjust for twin needle sewing with just the touch of a button.




Programmable Needle Up / Down

The needle can be programmed to stop in the highest *up* position, making it easier to remove fabric from the machine. The needle can be programmed to stop in the *down* position which is ideal for pivoting.



Specialty Needle Plate

Create perfect seam allowances on your projects. Gridlines in Metric and Imperial measurements are etched into the stainless steel needle plate.



Stitch Elongation


Select the elongation button and a variety of stitches can be made two to five times longer without losing stitch density.

Specialty Needle Plate

Seam allowance measurements are etched into the needle plate and printed on the bobbin cover for precise stitching. Angular markings including 30, 45, 60, 90 and 120 degrees are perfect for quilting .

Adjustable Presser Foot Pressure

Adjustable presser foot pressure allows you to adjust the amount of pressure exerted on your fabric while sewing. The setting of 3 will be optimal for most fabrics, but decrease the setting for delicate fabrics like chiffon or increase the setting for high pile fabrics. With up to 11 pounds of presser foot pressure, you never have to worry about fabric shifting.



Mirror Imaging

With just a touch of a button select stitches can be mirror imaged, adding even more stitch variety.

Drop Feed with Box Feed Motion

Lower the feed dogs for free-motion embroidery, monograms and for sewing buttons. The feed dogs move in a box motion ensuring perfect feeding throughout the entire feed process.

SINGER® | Studio S18

Included Presser Feet

All-Purpose Foot
 Button Sewing Foot
 Overedge Foot
 Narrow Rolled Hem Foot
 Zipper Foot
 Satin Stitch Foot
 Blind Hem Foot
 Cording Foot
 Overcasting Foot
 Buttonhole Foot
 Darning / Freehand Foot
 Quarter Inch Foot
 Even Feed / Walking Foot
 Open Toe Foot

Included Accessories

Screwdrivers (2)
 Needles
 Lint Brush
 Seam Ripper
 Thread Spool Caps (2)
 Bobbins (5)
 Edge / Quilting Bars (2)
 Adjustable Seam Guide
 Knee Lifter
 Instruction Manual
 Quick Start Guide
 Power Cord
 Foot Controller
 Accessory Storage Box
 Soft-Sided Dust Cover

Put Your Mind at Ease


The SINGER S18 Studio quilting and sewing machine comes with a limited 25-Year Warranty.

Help Button

Press this button to view alternative applications of certain stitches and the recommended presser foot.


Specifications

Weight: 26 pounds
 Dimensions: 20" length x 9" width, 14" height
 Sewing Space Light: 12 V, 5 W



Heavy Duty Metal Frame

Continue to sew while filling a bobbin! Simply follow the numbered diagram printed on the top of sewing machine and your bobbin is full in no time!




Answers At Your Fingertips

Toll-Free Helpline 1-800-4-SINGER (1-800-474-6437)
Monday through Friday, 8:00 a.m. to 4:00 p.m. C.T.

Online Support available any time at singerco.com
 Social Media Support allows you to connect with other sewers for tips and tricks!

YouTube.com/SingerSewingCompany offers a variety of helpful videos tutorials including the following topics:
 Threading, Presser Feet Training, Maintenance and Troubleshooting.

SINGER® | Studio S18



7 Fully Automatic Built-In Buttonhole Styles

Buttonhole sewing is a fully automatic one-step simple process providing reliable results every time.



Quilting Stitches Included

Perfect for all types of quilting! Modern Quilts, Crazy Quilts, Traditional Quilts & more.



Stitches

400+ Built-In Stitches with Stitch Reference Chart

This chart located on the upper lid of the machine allows you to quickly see all of the 408 built-in stitches and choose the perfect stitch for your project.

Quick Reference Board

A handy, removable Quick Reference Board easily attaches to the back of the machine to provide visual references for each stitch.

2 Styles of Alphabets & Numerals

Personalize projects by adding a monogram, name or phrase with the built-in block or script style numbers and alphabets, both available in upper and lower case, stitched at 5mm or 7mm stitch width.

10 Direct Selection Stitches

80 Quilting Stitches

60 Utility Stitches

258 Alphanumeric Stitches



Push-Button Stitch Selection

Ten of the most popular stitches are accessible with one touch. The rest of the stitches are just a few clicks away.

